

Instructions for Applying Heat Transfers to Isaac's Designs Apparel

You can use either a commercial heat press or a regular heat press to apply your iron-on transfer image to the fabric.

Using a commercial heat press, preheat the press to 385 Fahrenheit. First press the fabric smooth for a few seconds. This will also remove any moisture. Allow to cool.

Next, place the transfer face down in the desired position and press using light to medium pressure for 8 seconds.

Gently rub the transfer for a couple of seconds with a soft cloth and if light colored fabric peel the transfer backing right away, if it is a dark color fabric you may rub transfer and peel with 5 seconds or so.

Put to the side and continue production, quick, easy and best of all simple.